100 SERIES AWNING WINDOWS




Table of Awning Window Sizes

Scale $\frac{1}{8}$ " (3) = 1'-0" (305) - 1:96

Window Dimension			1'-5 1/2" (445)	1'-11 1/2"	2'-5 1/2" (749)	2'-11 ¹ /2" (902)	3'-5 ¹ /2" (1054)	3'-11 ¹ / ₂ " (1207)
Minimum Rough Opening			1'-6" (457)	2'-0"	2'-6" (762)	3'-0"	3'-6" (1067)	4'-0" (1219)
Unobstructed Glass			11 ¹ / ₄ " (286)	17 ¹ /4" (438)	23 1/4" (591)	29 1/4" (743)	35 ¹ / ₄ " (895)	41 ¹ / ₄ " (1048)
[1-11 1/2" 11-5 1/2" [597] (445) [2'-0" 1'-6"		CUSTOM HEIGHTS $-$ 17 1 /2" to 35 1 /2"	1616	2016	2616	3016	3616	4016
2'-5 1/2" (749) 2'-6"	23 ¹ / ₄ " (591)		1620 1626	2020	2620	3020	3620 3626	4020
2'-11 1/2" (902) 3'-0"	29 1/4" (743)		1630	2030	2630	3030	3630	4030



Custom-size windows are available in 1/8" (3) increments.




Choose venting or stationary. Awning windows must be installed to vent as shown and should not be rotated and used as a hopper.

Custom Sizes and Specification Formulas




100 Series custom-size windows are available in 1/8" (3) increments between minimum and maximum widths and heights shown. Some restrictions apply.

Awning Windows



Single



• Clear Opening formulas provide dimensions for determining area available for egress. Vent Opening formulas provide dimensions for determining area available for passage of air. Minimum R.O. (minimum rough opening) formulas provide minimum rough opening width and height dimensions. Unobst. Glass (unobstructed glass) formulas provide dimensions for determining area available for passage of light.

Dimensions in parentheses are in millimeters.

2022 100 Series Product Guide Page 1 of 1

^{• &}quot;Window Dimension" always refers to outside frame-to-frame dimension.
• "Minimum Rough Opening" dimensions may need to be increased to allow for use of building wraps, flashing, sill panning, brackets, fasteners or other items.

[·] Dimensions in parentheses are in millimeters.